“U”
Shower Rod

INSTALLATION INSTRUCTIONS

Parts Included

• 2 Corner Pieces • 1 Front Bar with Grey Inserts •
• 2 #300 Flanges • 8 Wall Screws • 2 Set Screws •

Tools Needed

• Pencil • Drill • Measuring Tape • Hacksaw (Optional) •

1. The bent corner rods and small straight rods attach together with the grey inserts as shown.

2. The flanges attach to the wall (measure for proper distance).

3. The U-Rod assembly fits into the flanges and is secured with set screws.

4. Rods can be adjusted to fit by cutting them with a hacksaw.

P 847•244•1234 | www.barclayproducts.com